



## YK 1100 - 11 HP

No.	P/N	Description	No.	P/N	Description	No.	P/N	Description
1	31-03 M	Recoil Starter Assy (Maroon)	17	36-61	Piston Ring	34	36-72	Valve Spring
1	31-03 B	Recoil Starter Assy (Black)	18	36-34	Piston Assy.	35	01-03	Head Cover Comp.
2		Recoil Starter Cup	19	36-17	Cam Shaft Assy.	36	99-13	Cylinder Head Assy.
3	01-35	Cooling Fan	20	36-89	Valve Lifter Assy	37	49-14	Carburetor Assy.
4	01-54	Fly Wheel	21	36-85	Push Rod	38	49-159	Air Cleaner/Spacer Gasket
5	49-45	Oil Seal	22	01-31	Control Assy.	39	49-149	Carburetor Gasket
6	36-50	Cylinder Barrel	23	50-08	Head Gasket	40	33-06	Ignition Coil Assy
7	33-12	Engine Stop Switch Assy	24	36-68	Valve Assembly In/Exhaust	41	30-06	Air Cleaner Element
8	33-20	Oil Level Switch Assy.	25	07-50	Fuel Tank Joint.	42	30-03	Air Cleaner Assembly
9	36-95	Governor Gear Assy.	26	33-11	Spark Plug	43	01-34 M	Fan Cover Comp. (Maroon)
10	36-08 Q	Crankshaft Assy.	27	35-10	Muffler Comp.	43	01-34 B	Fan Cover Comp. (Black)
11	50-43	Oil Pan Gasket	28	35-11	Muffler Protector	44	35-19	Spark Arrester
12	36-119	Crankcase and Oil Pan Assy.	29	07-10	Fuel Filter & Holder	45	35-47	Muffler Gasket
13	07-16	Oil Dip Stick	30	07-11	Fuel Tank Cap	46	35-49	Ex. Pipe Gasket
14	49-45	Oil Seal	31	07-08	Fuel Tank Assy.	47	36-78	Balancer Weight Assy.
15	45-04	Bearing	32	35-14	Exhaust Pipe Comp.			
16	36-26	Connecting Rod	33	36-74	Rocker Arm Assy.			

### Accessory Parts

No.	P/N	Description	No.	P/N	Description	No.	P/N	Description
	04-02	Recoil Starter Flange Bolt		33-22	Oil Alert Unit		49-23	Carburetor Float Set
	30-107	Air Cleaner Grommet		33-49	Electric Starter Motor Assy.		49-70	Generator Carb. Assy.
	30-115	Air Cleaner Wing Nut		35-05	Muffler Assy		49-70	Generator Carb. Assy. Electric Start
	33-15	Noise Suppressor Cap / Spark Plug Boot		49-04	Carburetor Repair Kit		49-86	Carb. Choke Lever Comp.
	33-20	Oil level Switch Assy		49-20	Carb. Float Chamber Set		99-06	Cylinder Barrel Assy.